

- 1.** Remove carefully USB cover from WTCS-1 (use a pin or flat knife)
- 2.** Insert battery, turn WTCS-1 on and connect it to PC
- 3.** Turn off WTCS-1, screen will freeze and your computer will start to install driver for WTCS-1, wait for message, it is done. In case driver will not install automatically, please install driver from Driver folder according to your Windows operating system version
- 4.** Run BETSO flash utility from BetsoFlash folder, choose latest FW file (with \*.dfu extension) and run the upgrade
- 5.** When upgrade is done, remove battery and insert it again and turn it on